


# Monarch XX Series Parts Manual

Touch Bar Exit Device





#### **Table of Contents**

XX Rim Exit Device - Panic	4-5
F-XX Rim Exit Device - Fire	6-7
(F)XX Rim Center Case - Panic and Fire	8-9
XX-V Surface Vertical Rod Exit Device - Panic	10-11
F-XX-V Surface Vertical Rod Exit Device - Fire	12-13
(F)XX-V Surface Vertical Rods and Latches - Panic and Fire	14-15
XX-C Concealed Vertical Rod Exit Device - Panic	16-17
F-XX-C Concealed Vertical Rod Exit Device - Fire	18-19
(F)XX-C Concealed Vertical Rods and Latches - Panic and Fire	20-21
(F)XX-C Concealed Vertical Top Latches and Plates - Wood and Metal Door, Panic and Fire	22-23
XX-M Mortise Exit Device - Panic	24-25
F-XX-M Mortise Exit Device - Fire	26-27
(F)XX-M Mortise Lock - Panic and Fire	28-29

#### Introduction

This manual contains a listing of replaceable parts and assemblies for the XX series exit device.

#### **How to Order**

Some parts are sold separately. Other parts are available as part of a kit or multiple quantity package. For the best possible service when ordering replacement parts or assemblies, please provide the following information:

- · Part number or assembly number
- Description
- · Quantity needed
- Finish desired (if available finish)


### **Part Number Changes**

This manual reflects the product as sold in November 2007. Because of changes to the product and/or manufacturing processes, part numbers can change.





### **XX Rim Exit Device**







### **XX Rim Exit Device**


Item No.	Qty.	Part No.	Description	Notes
1	1	3747	XX Lever Arm Left Hand	A
2	1	3767	XX Crossbar	A
3	1	3746	XX Lever Arm Right Hand	A
4	2	660025	1/4"-20 x 1/2" Crossbar Retaining Screw	
5	8	600140	#8-32 x 1/4" UFPHMS	A
6	8	660004	#10 x 1-1/4" PPHSMS	
7	2	3749	XX Axle	
8	4	660123	#8-32 x 1/4" UFPHMS	
9	1	2789	7/32" Hex Key	
10	1	584	XX End Case	
11	1	610044	Axle Support Assembly	
12	1	3741	XX End Case Cover	A
13	1	630015	F570 Roller Strike for Panic and Fire - Standard	
14	2	3770	Main Cam Springs	
15	1	585	XX Center Case Assembly ("EO" Function)	
16	1	3740	XX Center Case Cover	A

A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.





### F-XX Rim Exit Device







### F-XX Rim Exit Device

Item No.	Qty.	Part No.	Description	Notes
1	1	3747	XX Lever Arm Left Hand	Α
2	1	3767	XX Crossbar	Α
3	1	3746	XX Lever Arm Right Hand	Α
4	2	660025	1/4"-20 x 1/2" Crossbar Retaining Screw	
5	8	600140	#8-32 x 1/4" UFPHMS	Α
6	8	660004	#10 x 1-1/4" PPHSMS	
7	2	3749	XX Axle	
8	4	660123	#8-32 x 1/4" UFPHMS	
13	1	630015	F570 Roller Strike for Panic and Fire - Standard	
14	2	3770	Main Cam Springs	
17	1	684	XX End Case - Fire	
18	1	610214	Axle Support Assembly - Fire	
19	1	3741	XX End Case Cover - Fire	Α
20	1	685	XX Center Case Assembly - Fire	
21	1	4009	XX Center Case Cover - Fire	Α


A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.





## (F)XX Rim Center Case

**Panic and Fire** 







## (F)XX Rim Center Case

#### **Panic and Fire**


Item No.	Qty.	Part No.	Description	Notes
22	1	610070	18 Rim Back Cover Assembly	
23	1	3755	K-Hub	В

B. Used in K/L functions only.





### **XX-V Surface Vertical Rod Exit Device**







### **XX-V Surface Vertical Rod Exit Device**

Item No.	Qty.	Part No.	Description	Notes
1	1	3747	XX Lever Arm Left Hand	A
2	1	3767	XX Crossbar	A
3	1	3746	XX Lever Arm Right Hand	A
4	2	660025	1/4"-20 x 1/2" Crossbar Retaining Screw	
5	8	600140	#8-32 x 1/4" UFPHMS	А
6	8	660004	#10 x 1-1/4" PPHSMS	
7	2	3749	XX Axle	
8	4	660123	#8-32 x 1/4" UFPHMS	
9	1	2789	7/32" Hex Key	
10	1	584	XX End Case	
11	1	610044	Axle Support Assembly	
12	1	3741	XX End Case Cover	A
24	1	3742	XX Vertical Active Center Case Cover	
25	1	3566	Locking Cam Operator	
26	1	3762	Locking Cam	
27	1	660442	Retaining Ring	
28	1	3755	K-Hub	В
29	1	660446	Retaining Ring	
30	1	587	XX Vertical Active Center Case Assembly - Panic	


A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.



B. Used in K/L function only.



### F-XX-V Surface Vertical Rod Exit Device







### F-XX-V Surface Vertical Rod Exit Device


Item No.	Qty.	Part No.	Description	Notes
1	1	3747	XX Lever Arm Left Hand	A
2	1	3767	XX Crossbar	A
3	1	3746	XX Lever Arm Right Hand	A
4	2	660025	1/4"-20 x 1/2" Crossbar Retaining Screw	
5	8	600140	#8-32 x 1/4" UFPHMS	A
6	8	660004	#10 x 1-1/4" PPHSMS	
7	2	3749	XX Axle	
8	4	660123	#8-32 x 1/4" UFPHMS	
11	1	610044	Axle Support Assembly	
12	1	3741	XX End Case Cover	A
17	1	684	XX End Case - Fire	
18	1	610214	Axle Support Assembly - Fire	
19	1	3741	XX End Case Cover - Fire	A
31	1	3742	XX Vertical Active Center Case Cover	
32	1	3566	Locking Cam Operator	
33	1	3762	Locking Cam	
34	1	660442	Retaining Ring	
35	1	3755	K-Hub	В
36	1	660446	Retaining Ring	
37	1	587	XX Vertical Active Center Case Assembly - Fire	

A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.



B. Used in K/L function only.







## (F)XX-V Surface Vertical Rods and Latches

#### **Panic and Fire**


Item No.	Qty.	Part No.	Description	Notes
5	8	600140	#8-32 x 1/4" UFPHMS	A
38	1	630010	3788 Strike - Surface Vertical Rod Panic and Fire Devices - Standard	
39	2	660002	#10 x 1-1/4" FPHSMS	
39	2	660078	#10-24 x 3/4" FPHMS (Fire)	
40	1	588	Surface Vertical Top Latch Case Sub Assembly - Panic	
40	1	F588	Surface Vertical Top Latch Case Sub Assembly - Fire	
41	1	661102	1/8" x 3/4" Cotter Key	
42	2	660004	#10 x 1-1/4" PPHSMS	
42	2	660081	#10-24 x 3/4" PPHMS (Fire)	
43	2	660002	#10 x 1-1/4" FPHSMS	
43	2	660078	#10-24 x 3/4" FPHMS (Fire)	
44	2	3781	Latch Case Cover	Α
45	1	3777	Surface Vertical Top Rod Sub Assembly	
46	2	4400	Surface Vertical Rod Adjustment Screw	
47	2	590	Rod Guide and Support	А
48	1	610034	Surface Vertical Bottom Bolt and Rod Assembly	
49	1	610035	Surface Vertical Bottom Guide Assembly	Α
50	1	630013	2130 Strike - Surface and Concealed for Panic or Fire - Standard	

A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D





### **XX-C Concealed Vertical Rod Exit Device**







### **XX-C Concealed Vertical Rod Exit Device**


Item No.	Qty.	Part No.	Description	Notes
1	1	3747	XX Lever Arm Left Hand	A
2	1	3767	XX Crossbar	A
3	1	3746	XX Lever Arm Right Hand	A
4	2	660025	1/4"-20 x 1/2" Crossbar Retaining Screw	
5	8	600140	#8-32 x 1/4" UFPHMS	A
6	8	660004	#10 x 1-1/4" PPHSMS	
7	2	3749	XX Axle	
8	4	660123	#8-32 x 1/4" UFPHMS	
9	1	2789	7/32" Hex Key	
10	1	584	XX End Case	
11	1	610044	Axle Support Assembly	
12	1	3741	XX End Case Cover	A
51	1	4246	Lift Finger	
52	2	660065	#10-24 x 1/2" with Nylon Patch	
53	1	591	Active Center Case Assembly - Panic	

A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.





### F-XX-C Concealed Vertical Rod Exit Device







### F-XX-C Concealed Vertical Rod Exit Device

#### Fire

Item No.	Qty.	Part No.	Description	Notes
1	1	3747	XX Lever Arm Left Hand	A
2	1	3767	XX Crossbar	A
3	1	3746	XX Lever Arm Right Hand	A
4	2	660025	1/4"-20 x 1/2" Crossbar Retaining Screw	
5	8	600140	#8-32 x 1/4" UFPHMS	A
6	8	660004	#10 x 1-1/4" PPHSMS	
7	2	3749	XX Axle	
8	4	660123	#8-32 x 1/4" UFPHMS	
12	1	4128	Inactive End Case	
18	1	684	Inactive End Case Assembly	
19	1	610214	Axle Support Assembly - Fire	
20	1	3741	XX End Case Cover - Fire	A
51	1	4246	Lift Finger	
52	2	660065	#10-24 x 1/2" with Nylon Patch	
54	1	691	Active Center Case Assembly - Fire	


A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.





## (F)XX-C Concealed Vertical Rods and Latches

**Panic and Fire** 







## (F)XX-C Concealed Vertical Rods and Latches

#### **Panic and Fire**

36	1	661102	1/8" x 3/4" Cotter Key	
39	3	660002	#10 x 1-1/4" FPHSMS	
39	3	660078	#10-24 x 3/4" FPHMS (Fire)	
50	1	630013	2130 Strike - Surface and Concealed for Panic or Fire - Standard	
55	1	630012	4188 Strike - Concealed Vertical Rod Panic and Fire Devices - Standard	
56	1	610040	Top Latch Release Sub Assembly	A
57	2	660078	#10-24 x 3/4" FPHMS	A
58	1	610038	Top Rod Sub Assembly	
59	1	610037	Center Slide Sub Assembly	
60	1	610057	Bottom Rod Sub Assembly	
61	1	4567	Bottom Bolt Guide	

A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.







### (F)XX-C Concealed Vertical Top Latches and Plates

**Wood and Metal Door, Panic and Fire** 

#### **Metal Door**



#### **Wood Door**







# (F)XX-C Concealed Vertical Top Latches and Plates

#### Wood and Metal Door, Panic and Fire


Item No.	Qty.	Part No.	Description	Notes
5	6	4122	1/4"-20 Sex Bolt	Α
62	1	603	Concealed Top Latch Case Sub Assembly (Panic)	
63	1	F603	Concealed Top Latch Case Sub Assembly (Fire)	
64	6	660078	#10-24 x 3/4" FPHMS	
65	1	4834	Top Reinforcement Plate with Access Hole	A
66	1	4833	Top Reinforcement Plate	A
67	1	4832	Center Slide Reinforcement Plate	
68	4	660044	1/4"-20 x 3/4" FPHMS	Α
69	4	660429	1/4" CSK Finish Washer	Α
70	2	4694	Latch Bracket	

A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.





### **XX-M Mortise Exit Device**







### **XX-M Mortise Exit Device**


Item No.	Qty.	Part No.	Description	Notes
1	1	3747	XX Lever Arm Left Hand	A
2	1	3767	XX Crossbar	A
3	1	3746	XX Lever Arm Right Hand	A
4	2	660025	1/4"-20 x 1/2" Crossbar Retaining Screw	
5	8	600140	#8-32 x 1/4" UFPHMS	A
6	8	660004	#10 x 1-1/4" PPHSMS	
7	2	3749	XX Axle	
8	4	660123	#8-32 x 1/4" UFPHMS	
9	1	2789	7/32" Hex Key	
10	1	584	XX End Case	
11	1	610044	Axle Support Assembly	
12	1	3741	XX End Case Cover	A
13	1	630015	F570 Roller Strike for Panic and Fire - Standard	
71	1	600117	Lift Finger with Mounting Screws (Panic Device Only)	
72	1	586	XX Mortise Active Center Case Assembly - Panic	
73	1		Mortise Lock - 8500 x Function x Handing	A

A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.





### **F-XX-M Mortise Exit Device**







### F-XX-M Mortise Exit Device

#### **Fire**

Item No.	Qty.	Part No.	Description	Notes		
1	1	3747	XX Lever Arm Left Hand	A		
2	1	3767	XX Crossbar	A		
3	1	3746	XX Lever Arm Right Hand	A		
4	2	660025	1/4"-20 x 1/2" Crossbar Retaining Screw			
5	8	600140	#8-32 x 1/4" UFPHMS	A		
6	8	660004	#10 x 1-1/4" PPHSMS			
7	2	3749	XX Axle			
8	4	660123	#8-32 x 1/4" UFPHMS			
18	1	684	Inactive End Case Assembly			
19	1	610214	Axle Support Assembly - Fire			
20	1	3741	XX End Case Cover - Fire	A		
73	1		Mortise Lock	A		
74	1	600107	Lift Finger with Mounting Screws (Fire Device Only)			
75	1	686	XX Mortise Active Center Case Assembly - Fire			


A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.






## (F)XX-M Mortise Lock

#### **Panic and Fire**









### (F)XX-M Mortise Lock

#### **Panic and Fire**

Item No.	Qty.	Part No.	Description	Notes		
9	2	660120	#8-32 x 1/4" PPHMS			
76	1	3532	Dead Locking Arm			
77	1	3518	Dead Lock Arm Spring	D		
78	1	3531	Auxiliary Bolt Spring			
79	1	3530	Auxiliary Bolt Actuator			
80	1	3521	Actuating Arm			
81	1	610041	Mortise Latch Bolt Assembly			
82	1	4025	Cylinder Screw Retainer	С		
83	1	610042	Locking Arm and Spring Assembly	C & D		
84	2	660068	#10-24 x 1/2" PPHMS Type "F"			
85	1	3522	Main Lift			
86	1	3523	T-Lift			
87	1	3516	T-Lift Spring			
88	1	3529	Auxiliary Bolt			
89	1	3515	Mortise Lock Face	E		
90	2	660068	#10-24 x 1/2" PPHMS	E		
91	2	660128	#8-32 x 2" FIL HD MS (US-26, US-26D)	E		
91	2	660129	#8-32 x 2" FIL HD MS (US-3, US-4, US-10, US-10B)			
92	1	610067	Mortise Lock Housing Assembly			
93	1	3540	Mortise Back Cover			
94	1	3519	Mortise K-Hub	B&C		
95	1	3542	Clinder Operating Arm	C & F		

- A. Specify by finish: US-3, US-4, US-10, US-10B, US-26, US-26D, US-32, US-32D.
- B. Used in K/L trim functions only.
- C. Omit for "BE" trim function.
- D. Dead lock arm spring (Part No. 3518) required for NL function. Remove existing spring and screw from locking arm for NL.
- E. Available only in US-3, US-4, US-10, US-10B, US-26, US-26D.
- F. Used in NL function only.









Ingersoll Rand's Security Technologies Sector is a leading global provider of products and services that make environments safe, secure and productive. The Sector's market-leading products include electronic and biometric access control systems; time and attendance and personnel scheduling systems; mechanical locks and portable security, door closers and exit devices, steel doors and frames, architectural hardware and technologies and services for global security markets.

800.266.4456 Locks 800.826.5792 Exit Devices 800.815.1517 Closers www.falcon.ingersollrand.com www.ingersollrand.com